



| 13p-DIN | color | SIGNAL | replacement | 14p-Binder conn.pins | comment |
|---------|--------------|----------------|-------------|----------------------|---|
| 1 | brown | hi E1 string | P | P | hexaphonic(single string)outputs, hiE1 |
| 2 | blue | B | O | O | |
| 3 | gray | G | N | N | |
| 4 | orange | D | M | M | |
| 5 | pink | A | U | U | |
| 6 | purple | low E6 string | T | T | low E6 |
| 7 | gn | Gtr Signal | G | G | (grounded,if Mode-switch="Synth only") |
| 8 | yel-blk | synth(MIDI)Vol | E | E | (0..5V DC; grounded: MIDI Vol = off!) |
| 9 | yellow | see *) | J | J | GK-Mode-switch -control voltage, see *) |
| 10 | red | S1 Pgm Down | S | S | (Sw1, active low = grounded,when pressed) |
| 11 | wht-blk | S2 Pgm Up | R | R | (Sw2, active low = grounded,when pressed) |
| 12 | white | + power (+7V) | A | A | |
| 13 | black | - power (-7V) | L | L | |
| | Case contact | ground | C | C | (connect also to Binder CASE) |

- V1 2018-07-14 Seymour Duncan Jazz & 59
- V2 2019-01-03 Gibson Pickups (490R, 490T)
- V3 2019-10-02 + Varitone Switch
- V4 2022-11-02 - Varitone Switch > SC-Switch

WIRING V4
Eastman T-486
 Sigi Flamisch