



13p-DIN pins	Roland GK-x-SIGNAL
1 .. 6	1 hi E ... 6 low E
7	Gtr PU signal
8	Synth (MIDI) Vol 0..5V DC
9	unused
10	S1 Pgm Down
11	S2 Pgm Up
12	+ power (+7V)
13	- power (-7V)
case	ground