



- 13p-DIN Roland GK-x-SIGNAL pins**
- 1 .. 6: 1 hi E ... 6 low E
  - 7: Gtr PU signal
  - 8: Synth (MIDI) Vol 0..5V DC
  - 9: unused
  - 10: S1 Pgm Down
  - 11: S2 Pgm Up
  - 12: + power (+7V)
  - 13: - power (-7V)
  - case: ground